


Better Collaboration. Clearer Design Reviews. Faster Project Delivery.

Take Control with Viewer+



From design to delivery, work smarter and faster with Viewer+.

Empower every team member with greater access, visibility, and control to review, validate, and collaborate on iBwave Design files.

No more bottlenecks. No more static design files. No more fragmented communication. Just faster execution.


Review and Interact with Designs with Clarity & Control

Access the details you need, when you need them.

Control Your View & See What Matters

Lock/unlock, show/hide and shift layers, toggle legends, and move parts and labels for clearer, focused design analysis.

- Review Key Component & Material Details Quickly access properties of radios, cables, walls, and other parts and materials.
- Ensure Cross-Floor Consistency Review floor siblings and verify connector links for seamless installation.
- Validate Setup with Confidence Easily verify building, system, and floor plan details.
- Understand Network Performance at a Glance Visualize survey and prediction data, enhanced with 3D views.



Eliminate Bottlenecks & Streamline Collaboration


Stay aligned across project teams.

Leave Feedback with Ease

Add comments or annotate design changes directly on floor plans and export them in a report for seamless communication.

Unlock More Reports for Better Insight Access comprehensive, shareable reports, including Output Maps, Cable Routing, Antenna, and more, to ensure teams are aligned.

Execute Seamlessly Across Teams From design reviewers to project leads and installers—enable everyone with the access and details they need to complete their job independently and move projects forward faster.



Efficiency and Collaboration Redefined.

Deliver seamless execution from review to deployment—with speed, clarity, and control.

Which Version is Right for You?

| FEATURE | VIEWER | VIEWER+ |
|---|--------------|--------------|
| REVIEW & ANALYSIS | | |
| OPEN & VIEW PROJECTS | \bigcirc | \bigotimes |
| VIEW DESIGN FILES IN 3D | \bigcirc | \bigotimes |
| VIEW PREDICTION & SURVEY DATA | \bigcirc | \bigotimes |
| EXPORT PLAN TO IMAGE | \bigcirc | \bigotimes |
| VIEW OUTDOOR PREDICTIONS FROM IBWAVE REACH | \bigcirc | \bigotimes |
| VIEW COMPONENT PROPERTIES | | \bigotimes |
| VIEW WALL MATERIAL PROPERTIES | | \bigotimes |
| VIEW BUILDING & PLAN PROPERTIES | | \bigotimes |
| VIEW SYSTEM PROPERTIES | | \bigotimes |
| VIEW FLOOR SIBLING | | \bigotimes |
| VIEW CONNECTOR INFO | | \bigotimes |
| ACCESS & CONTROL | | |
| SHOW/HIDE & MOVE LAYERS | \bigcirc | \bigotimes |
| LOCK & UNLOCK LAYERS | | \bigotimes |
| ADD, DELETE & TURN LEGENDS ON/OFF | | \bigotimes |
| MOVE PARTS & LABELS | | \bigotimes |
| MOVE & RESIZE PICTOGRAMS & PUSHPINS | | \bigotimes |
| ADD RULER | | \bigotimes |
| MULTISELECT WALLS & COMPONENTS | | \bigotimes |
| EXPORT A BUILDING TO GOOGLE EARTH | | \bigotimes |
| COLLABORATION | | |
| ADD ANNOTATIONS/COMMENTS & EXPORT IN A REPORT | | \bigotimes |
| VIEW ANNOTATIONS | | \bigotimes |
| OPEN & REVIEW PROJECTS DIRECTLY FROM IBWAVE UNITY | | \bigotimes |
| REPORTING | | |
| > OUTPUT MAPS | \bigcirc | \bigotimes |
| > COMPLIANCE | \bigcirc | \bigotimes |
| > SURVEY DATA | \bigcirc | \bigotimes |
| > EQUIPMENT LIST | \bigcirc | \bigotimes |
| > ANNOTATIONS | \bigotimes | \bigotimes |
| > AREA | \bigcirc | \bigotimes |
| > ANTENNAS | | |
| > CABLE ROUTING | | \bigotimes |





iBwave Viewer+ Datasheet-02-EN_2025-06-12 ©iBwave Solutions Inc. 2004-2025 All Rights Reserved